

CAVALIO 0.3 · CAVALIO 0.55

Supplier	Roller adhesives / Dry adhesives
ARDEX GmbH	AF 185
BOTAMENT Systembaustoffe GmbH & Co. KG	BOTAMENT K 572
G.A. Kiesel GmbH	Okatmos RF 220
Sika Deutschland GmbH	iFLOOR
PCI Augsburg GmbH	DT 100 DT 200
Uzin Utz AG	U 3000
Uzin Utz AG	SWITCHTEC Sigan 1, 2 * Sigan Elements Sigan Elements Plus
Wakol GmbH	D 3330

* The suitable substrates from Sigan 1,2 can be found at www.uzin-utz.com.

Design floor coverings must be air conditioned for at least 48 hours on site and they must be carefully rolled or rubbed down after being laid.

Roller adhesives and dry adhesives allow greater change in floor covering dimensions.

All the adhesives that we recommend must be used in accordance with the respective manufacturer's specifications.

Any adhesives that are not listed in this recommended list have not been tested. They have not been tested for compatibility with our products.

Note:

A thermosetting resin adhesive must be used when installing design floor coverings in conservatories or rooms with large banks of windows with a high level of solar radiation.