

## CAVALIO 0.3 · CAVALIO 0.55

Supplier	Wet adhesives
ARDEX GmbH	AF 2224 AF 140
Bostik GmbH	Power Elastic
BOTAMENT Systembaustoffe GmbH & Co. KG	BOTAMENT K 530 BOTAMENT K 530 Faser
Forbo Erfurt GmbH	528 Eurostar Allround 643 Eurostar Fibre
G.A. Kiesel GmbH	Okatmos star 110
MAPEI GmbH	Ultrabond Eco V4 SP Ultrabond Eco 4 LVT
PCI Augsburg GmbH	PKL 326 K 188 S
Sika Deutschland GmbH	Durocoll
STAUF Klebstoffwerk GmbH	STAUF D50
Uzin Utz AG	KE 66
Wakol GmbH	D 3318
WULFF GmbH u. Co. KG	Supra-Strong Multi-Strong Ultra-Strong

The adhesives shown here require a consistently absorbent base.

The design floorcovering has to be rolled or rubbed down carefully after it is installed.

All the adhesives that we recommend must be used in accordance with the respective manufacturer's specifications.

Only those adhesives are suitable for the application and use.

Any adhesives that are not listed in this recommended list have not been tested. They have not been tested for compatibility with our products.

**Note:**

**A thermosetting resin adhesive must be used when installing design floorcoverings in conservatories or rooms with large banks of windows with a high level of solar radiation.**